

Manufacturer	Model	Year	Kit Number
Asterix	Havoc	2008-2011	7002
Azonic	B52	2009-2012	7010
Banshee	Legend MKII	2008-2012	7002
Banshee	SCYTHE	2009-20012	7009
Banshee	SCYTHE	2006-2008	7009
Banshee	Wildcald	2007-2011	7009
Canfield Brothers	Formula 1 Jedi	2007-2011	7002
Canfield Brothers	Can-diggle	2007-2011	7002
Canfield Brothers	One	2008-2011	7002
Canfield Brothers	Lucky	2007	7002
Commencal	Meta All		7002
Commencal	4X		7002
Commencal	Furious	2009-2011	7002
Commencal	Supreme	2009	7002
Commencal	Supreme 6		7002
Commencal	FR		7002
Commencal	Mini DH	2006-2008	7002
Commencal	Supreme DH	2006-2008	7002
Commencal	Supreme DH	2009-2011	7002
Evil	Revolt	2009-2011	7050
Giant	Glory	2006-2009	7008
Giant	Glory	2010-2011	7104
Giant	Faith	2004-2007	7008
			7002
Giant	Trance	2011	(note: will only take 1 offset bushing 22/8mm we split a pair for RRP \$45)
GT	Fury	2010-2012	7001
IBIS	Mojo	2006-2011	7009
IBIS	Mojo SL	2006-2011	7009
IBIS	SLR	2011-2012	7009
IBIS	Mojo HD 140/160mm	2011-2012	7009
Intense	M3	2006-2008	7006
Intense	M6	2008-2010	7005
Intense	M9	2010-2012	7005
Intense	951	2010-2012	7005
Intense	5.5	2004-2008	7004
Intense	6.6		
Intense	Socom	2006-2008	7005
Intense	Spider	2004-2008	7004
		2007	
Kona	Stinky	(other model years TBC)	7011
Lapierre	DH 720/920	2008-2010	7001
Lapierre	DH 720/920	2011	7001
Mondraker	Foxy	2008-2010	7002
Mondraker	Dune	2008-2010	7002
Mondraker	Summon	2009-2011	7051
Mondraker	Foxy	2011	7051
Mondraker	Dune	2011	7051
Mondraker	Kaiser	2009-2011	7002
Mongoose	Boot'r	2009-2011	7001
Mongoose	Pinn'r	2009-2011	7001
Orange	Five	All Years	7002
Orange	Patriot	All Years	7002
Orange	Alpine 160mm	All Years	7002
Orange	222	All Years	7002
Orange	223	All Years	7002
Orange	224	All Years	7002
Orange	224 Evo	All Years	7002
Rocky Mountain	Flatline	2010-2011	7002
Rocky Mountain	Flatline	2008-2009	7002
Rocky Mountain	RM9	2001	7002
Rocky Mountain	RMX	2007	7002
Rocky Mountain	Slayer SS	2007-2010	7002
Santa Cruz	V10	2005-2011	7002
Santa Cruz	V10 Carbon	2011-2012	7002
Santa Cruz	Driver 8	2009	7002
Santa Cruz	Blur	2007 onwards	7002
Santa Cruz	Blur LT2	2007 onwards	7002
Santa Cruz	Heckler	2007 onwards	7002
Santa Cruz	VP Free	2005-2007	7002
Santa Cruz	Nomad (Carbon)	2010-2011	7002
Santa Cruz	Bullit	2007-2011	7002
Scott	Gambler	2008-2011	7002

Code Details	
7001	Burgtec 19.0mm x 8.1mm 19.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7002	Burgtec 22.0mm x 8.1mm 22.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7003	Burgtec 30.0mm x 8.1mm 30.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7004	Burgtec 22.0mm x 6.1mm 41.0mm x 6.1mm Slackening Shock Reducer & Sleeve
7005	Burgtec 33.6mm x 8.1mm 41.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7006	Burgtec 33.6mm x 8.1mm 33.6mm x 8.1mm Slackening Shock Reducer & Sleeve
7007	Burgtec 30.0mm x 8.1mm 41.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7008	Burgtec 30.0mm x 8.1mm 35.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7009	Burgtec 22.0mm x 8.1mm 40.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7010	Burgtec 22.0mm x 8.1mm 30.0mm x 8.1mm Slackening Shock Reducer & Sleeve
7011	Burgtec 22.0mm x 6.1mm 22.0mm x 6.1mm Slackening Shock Reducer & Sleeve

\* Highlighted items currently in stock 1 Nov 2011

Solid	Mission 9	2007-2011	7002
Specialized	Pitch	2008-2011	7002
Titus	El Guapo	2007-2011	7002
Tomac	Primer	2008-2009	7010
Transition	TR 450	2009-2012	7002
	TR 250	2009-2012	7002
	Blindside	2007-2010	7002
	Bottle Rocket	2007-2010	7002
	Covert	2007-2010	7002
Trek	88	2009-2011	7052
Turner	DHR	2011	7002
	5 Spot	All Years	7011
	Flux	All Years	7011
	Spot	All Years	7011
	Sultan and Sultan 29er	All Years	7011
	XCE	All Years	7011
Yeti	303 DH	2006-2008	7002